

**No connection with PC...**

Max Dwell duration with "manual"

With a switch between "pin 8" and "ground" You can activate the second chart.

Flashing zone for a gear shift light ( 12 V "+". Pin 3 "ground" )

**No connection with PC...**

Sometimes, the wires of channels are inverted. So you must reverse the numbers of lobes in the software.

**No connection with PC...**

Never change this "base advance = 3°"

RPM	500	1500	1700	2000	2300	2700	3100	3600	4100	4800	5500	6400	7400	8500	9000
Advance	5	5	9	14	17	21	24	27	29	30	31	32	32	32	17

**No connection with PC...**

26  
12/07/2019  
Ech = 1:X

Sachs Roadster 800 / Suzuki VS 800GL Intruder / Suzuki VX 800 USA CA  
IgniTech TCI-P4 V96 (updated V88) . Keying with Clouseau Stage 1 .

